


BETRIEBSANLEITUNG  
OPERATING INSTRUCTIONS  
INSTRUCTIONS DE SERVICE  
ISTRUZIONI D'USO  
HANDLEIDING  
INSTRUCCIONES PARA EL MANEJO  
MANUAL DE INSTRUÇÕES  
NAUDOJIMOSI INSTRUKCIJA  
KASUTUSJUHEND  
LIETOŠANAS INSTRUKCIJA  
DRIFTSINSTRUKS  
DRIFTSINSTRUKTIONER  
DRIFTSVEJLEDNING  
INSTRUKCJA OBSŁUGI

KEZELÉSI ÚTMUTATÓ  
NÁVOD K OBSLUZE  
NAVODILO ZA UPORABO  
NÁVOD NA OBSLUHU  
UPUTE ZA RAD  
MANUAL DE OPERATII  
TREORACHA OIBRIÚCHÁIN  
ΟΔΗΓΙΕΣ ΧΡΗΣΗΣ  
EL KITABI  
ИНСТРУКЦИИ ЗА ЕКСПЛОАТАЦИЯ  
ИНСТРУКЦИЯ ПО ЕКСПЛОАТАЦИИ  
取扱説明書  
사용설명서  
使用说明书

# VXLF 2.200

# VXLF 2.250

**MAKE IT BECKER.**



<input checked="" type="checkbox"/> <b>AIR</b>	

**1**

<b>MAX. VACUUM</b>		<b>mbar</b>
DIN EN ISO 11203 Accuracy Class 2 $K_{pA} = 3 \text{ dB(A)}$ $l \leftarrow 1\text{m}$		$L_{pA} = 75-80 \text{ dB(A)} - 50\text{Hz}$ $L_{pA} = 77-82 \text{ dB(A)} - 60\text{Hz}$

**2**

<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	222-280 kg 490-617 lbs

**3**

$A > 400\text{mm}$ $A > 16''$			
	$> 5^\circ\text{C}/41^\circ\text{F}$ $< 45^\circ\text{C}/113^\circ\text{F}$	max. 90%	max. 800m

**4**

No. 2	
5 mm	
13 mm	

**5**

**6**

**BECKER** MADE IN GERMANY EN ISO 9001 CE

50 Hz 3000W 60 Hz 3000W

22.000 RPM/A 22.000 RPM/A

3000-0000 mm 3000-0000 mm

7

**GENERAL**

<sup>1)</sup> motor protection switch

**ADDITIONAL**  $M \geq 5.5 \text{ kW}$

**RECOMMENDATION**

**A**

Softstart

**B**

**OPTIONAL**

ON (I) -

OFF (0) -

$\geq 60s$

MAX 6x/h

PTC

Bi-metal

8

9

10

0 2 3 10[m]

2 1/2" 2 1/2" 3" + 1x

**VACUUM**

11

**AIR**

$>100^{\circ}\text{C}$

$>212^{\circ}\text{F}$

12

**Maintenance**



13

OFF



**n=0min<sup>-1</sup>**



14

**CLEANING INTERVAL**

SUCTION AIR

40h

200h

EN149 - FFP3  
42 CFR 84 - N100


15

16


17

VXLF 2.xxx **SK**


18




19




20




21







22



23



24





29



[WWW.BECKER-INTERNATIONAL-SHOP.COM](http://WWW.BECKER-INTERNATIONAL-SHOP.COM)

Gebr. Becker GmbH  
Hoelker Feld 29-31  
42279 WUPPERTAL  
GERMANY  
[info@becker-international.com](mailto:info@becker-international.com)  
[www.becker-international.com](http://www.becker-international.com)





**MAKE IT BECKER.**

28100052212 | 2021-07-08 | All rights reserved